

Prep is an essential part of painting your surfaces for success. Fusion Mineral Paint™ has exceptional adhesion, coverage and durability and dries to a smooth matte finish with a built-in top coat.

A little prep goes a long way to ensure your projects last the test of time!

HOW TO PREP FOR SUCCESS!

STEP 1

Clean your furniture from dirt, oil and grease using Fusion™ TSP Alternative.

STEP 2


Choose your surface and follow the recommended prep tips.

High Gloss Paint, Lacquer or Varnish.



Scuff sand with 220 grit and remove dust.

Soft Wax, Siliconized Polish or New Metal with Oil coating remaining on surface after cleaning.



Use Odourless Solvent or mineral spirits to remove soft wax and loose oil.

Old Paint or Finishes with a matte up to semi-gloss sheen, Non-Rusting Metal, Glass and dull Plastic finishes.



Bleed through or Knots to seal.



Apply Zinsser BIN Shellac Primer.

Melamine, Thermofoil or Laminate that are super slick. Extremely detailed high gloss carvings that can't be scuff sanded.



Apply a VERY thin coat of Ultra Grip, an ultra adhesive primer for these difficult surfaces.

paint it beautiful™

Do I need a primer? Fusion™ is self priming, 95% of paint jobs do not require a primer. People often use a primer to go from a dark colour to a light colour. Instead of this, try using a transition colour like Sterling grey to help cut down the number of required coats. These lighter mid-tone colours will act as a colour transition making the switch to pure whites easier. If you wish to block knots or are worried about tannin bleed through, apply BIN shellac based primer prior to Fusion Mineral Paint™.